COOKTOP, BURNER AND GRATE PARTS

For Models: KGCC505HBL04, KGCC505HWH04, KGCC505HBT04
(Black) (White) (Biscuit)

KitchenAid®

30" GAS GLASS SURFACE COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP, BURNER AND GRATE PARTS

For Models: KGCC505HBL04, KGCC505HWH04, KGCC505HBT04
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	4455834	Installation Instructions
	4456479	Use & Care Guide
	3192098	Wiring Diagram
	9759440	Conversion Instructions
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips
2		Grommet, Glass
	3180081	White
	3180079	Black
	3191817	Biscuit
3		Bezel, Cooktop (RF)
	9753601GS	Mouse Gray
	9753601GB	Black
4		Bezel, Cooktop (LF)
	9753600GS	Mouse Gray
	9753600GB	Black
5		Bezel, Cooktop (LR,RR)
	9753602GS	Mouse Gray
	9753602GB	Black
6		Cap, (RF)
	3191729	Mouse Gray
	3191728	Black
	3191730	Moleskin
7		Cooktop, Glass
	4455579	White
	4455577	Black
	4455580	Honeycomb
	3191933	Seal, Foam
8		Cap, (RR)(LR)
	3191735	Mouse Gray
	3191734	Black
	3191736	Moleskin
9		Cap, (LF)
	3191738	Mouse Gray
	3191737	Black
	3191739	Moleskin
10		Grate, Burner RH
	9759490	Mouse Gray
	9759489	Black
	9759491	Moleskin
11		Grate, Filler
	9759493	Mouse Gray
	9759492	Black
	9759494	Moleskin
12		Knob, Control (4)
	3191923	White
	3191922	Black
	3191925	Biscuit
15		Holder, Orifice
	4456621	RF − 6K (Auxi)
	4456623	LR−9K (Semi−Rapid)
	4456621	RR − 12K (Rapid)
	4456619	LF − 14K (Turbi)
16		Head, Burner
	4455979	RF − 6K (Auxi)
	4455981	LR−RR 12K (Rapid)
	4455849	LF
18	4449809	Screw
20	3368921	Screw, 7−18 X 3/4
21		Grate, Burner LH
	9759487	Mouse Gray
	9759486	Black
	9759488	Moleskin

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCC505HBL04, KGCC505HWH04, KGCC505HBT04
(Black) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCC505HBL04, KGCC505HWH04, KGCC505HBT04
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8286099	Rail, Burner
2	9759355	Pipe, Manifold
3	4456816	Valve, Gas Burner Burner, (RF)
4	3191387	Seal, Shaft
5	4456817	Valve, Gas Burner (RR & LR)
6	4456818	Valve, Gas Burner (LF)
7	3192819	Rail, Center
8	3186217	Bolt, Gas Valve
9	3177991	Screw
12	4456905	Harness & Switches
14	3191324	Tubing, Gas Burner (RF)
15	3191326	Tubing, Gas Burner (LF)
16	3191325	Tubing, Gas Burner (RR)
17	3191327	Tubing, Gas Burner (LR)
18	3191462	Shield, Heat (2)
22	9759148	Burner Box
	3179776	Screw
27	8522423	Module Spark
	3400843	Screw
28	3192491	Bracket, Support
29	3196160	Screw, 8−18 x 1/4

OPTIONAL PARTS

For Models: KGCC505HBL04, KGCC505HWH04, KGCC505HBT04
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

3192231	Cord, Power
4173634	Bushing
3177991	Screw
9759145	Bracket, Mounting
3400843	Screw
4167077	Nut, Tinnerman

Miscellaneous

4455918	Hardware, Mounting
4455917	Bracket, Cooktop Mounting
3400093	Screw
3192741	Conversion Kit Natural Gas To L.P.

WIRING HARNESS PARTS

4456626	Harness, Ignitor 15" (2)
4456627	Harness, Ignitor 28" (2)